




mockingbird



Bassinet Stand

Go from strolling to naptime without missing a beat.



Failure to follow these warnings and the instructions could result in death or serious injury. Before use please read and follow all of these instructions to ensure the safety of your child. Keep these instructions for future reference.

CHOKING HAZARD

Adult assembly required due to **small parts**. Keep assembly parts out of reach of children. Remove and discard packing material before using this product.


FALL HAZARD

- To help prevent falls, do not use this product when the infant begins to push up on hands and knees or has reached a maximum weight of 20 lbs (9.07 kg), whichever comes first.
- Always check that the Bassinet is securely locked on the Bassinet Stand by pulling upwards on the Bassinet.

GENERAL WARNINGS

- This Bassinet Stand is only compatible with the Mockingbird Bassinet. Read and follow all the instructions for your Mockingbird Bassinet.
- Make sure the Bassinet Stand is fully erect and latched in the open and locked position before allowing children near the Bassinet Stand.
- Avoid injury, make sure all body parts are clear of the Bassinet Stand when folding and unfolding.
- Maximum weight for Bassinet Stand storage basket is 45 lbs (20.4 kg).
- Keep removable storage basket away from children when removed.
- Never use Bassinet Stand with more than one child at a time.
- Never allow Bassinet Stand to be used as a toy.
- Regularly inspect Bassinet Stand for damage. Do not use if any parts are broken, damaged, or missing.
- If you're unable to securely attach Bassinet to your Mockingbird Bassinet Stand, remove all parts and contact the Mockingbird Customer Experience Team at support@hellomockingbird.com or text us at 646.933.1290 (US).

First, unpack the box and make sure you've got everything





Bassinet Stand

1

Open the Bassinet Stand

Open the frame


Press inner black buttons on both sides and pull the Bassinet Stand open. The Bassinet Stand will “CLICK” into place once fully open. Push against the frame on both sides to ensure it is locked.



2

Attach the Bassinet



Place the Bassinet into the right and left joints until it “CLICKS” into a fully locked position. Pull up on both sides to check it is locked. Press the white buttons located on both sides of the Bassinet Stand and lift Bassinet upward to fully remove.



3

Using the basket

Store all of your little one's naptime essentials down below in the storage basket. There's also a pocket on the side for smaller items.




Pro Tip

If needed, the basket can be completely removed by undoing the snaps on both sides.

4

Closing the Bassinet Stand

After removing the Bassinet, press inner black buttons on both sides of the Bassinet Stand and pull it closed.



When things get messy

Cleaning the basket



Machine wash in
warm water



Tumble dry low or
hang dry



Do not iron or
dry clean



Do not bleach

Cleaning the stand



Hand wash with damp
cloth and mild cleaning
solution if needed

